I'm not a robot

Panasonic Telephones offer various methods to block calls. Some of the common methods are: Block a single number - Blocks calls from specific phone numbers stored in the call block list. Block a range of numbers - Blocks calls that begin with a number pattern, e.g., a toll-free phone number prefix or an area code. Block unknown number - The unit blocks calls that have no phone number. Automated call block - Block all callers except those on the allow list. Note: You must subscribe to Caller ID to use Call Block. When a call is received, the unit rings once while caller information is being received. If the caller's phone number matches an entry in the call block list, the unit emits no sound to the caller and disconnects the call. Block options and programming methods vary by telephone model. Select your model from the drop-down list below for information on the current and programming. If your model is not listed or to view all of the Block options, refer to your model's Operating Manual for the specific procedure. Select the digits that your telephone model starts with, then press "Confirm". --- KX-PRD260. KX-PRD262 KX-PRL262 KX-PRS120 KX-PRW130 KX-TG113CSK KX-TG133CSK KX-TG153CSK KX-TG163CSK KX-TG175CSK KX-TG215SSK KX-TG243CSK. KX-TG433SK KX-TG27SCSK KX-TG3634. KX-TG3645 KX-TG365SK KX-TG383SK KX-TG385SK KX-TG395CSK/SK KX-TG432SK. KX-TG433CSK KX-TG443CSK. KX-TG443CSK KX-TG444SK KX-TG454SK. KX-TG465CSK/SK KX-TG472SK. KX-TG473SK KX-TG484SK KX-TG572SK. KX-TG573SK KX-TG583SK KX-TG3845 KX-TG385SK, KX-TG395CSK/SK KX-TG432SK, KX-TG433CSK KX-TG443CSK, KX-TG443CSK KX-TG444SK KX-TG454SK, KX-TG465CSK/SK KX-TG472SK, KX-TG473SK KX-TG484SK KX-TG572SK, KX-TG573SK KX-TG583SK KX-TG591 KX-TG6592 KX-TG674SK KX-TG684SK KX-TG7122SK KX-TG744SK KX-TG784 KX-TG785SK KX-TG787 KX-TG8052, KX-TG8053 KX-TG832SK, KX-TG833SK KX-TG885SK KX-TG954, KX-TG955 KX-TG985SK KX-TG994SK KX-TGB310, KX-TGB312 KX-TGB81 KX-TGB85 KX-TGC200, KX-TGC202 KX-TGC21, KX-TGC22, KX-TGC253 KX-TGC35, KX-TGC36, KX-TGC38 KX-TGD21, KX-TGD22 KX-TGD39 KX-TGD43 KX-TGD51, KX-TGD53 KX-TGD56, KX-TGD58, KX-TGD61, KX-TGD63 KX-TGD66 KX-TGD810, KX-TGD86 KX-TGD890, KX-TGD892 KX-TGE21, KX-TGE23, KX-TGE24 KX-TGE26, KX-TGE27 KX-TGE43, KX-TGE445 KX-TGE46, KX-TGE47, KX-TGE48 KX-TGE63, KX-TGE64 KX-TGE66, KX-TGE67 KX-TGF34 KX-TGF35 KX-TGF37 KX-TGF380, KX-TGF382, KX-TGF383 KX-TGF54 KX-TGF57 KX-TGF75 KX-TGF77 KX-TGF853, KX-TGF87 KX-TGF892 KX-TGF944 KX-TGF973 KX-TGF975 KX-TGU40 KX-TGU432, KX-TGU433, KX-TGUA40 Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 100 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 100 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. Block a single number with the Call Block Button You can press the [CALL BLOCK] button in the following situations to disconnect the current call and add a phone number to the call block list: When an incoming call is being received. When an incoming call is being recorded by the answering system (for models with a built-in answering machine). When talking on an outside call. Once a phone number has been added to the call block list, the unit will block calls from that phone number in the future. Press the [CALL BLOCK] button under the situations shown above. Confirm the call block number and press [YES]. The call block number is stored in the call block list, "Caller blocked" is displayed, and then the call is disconnected. Note: If the call has no phone number, the call is blocked but it is not stored in the call block list. The call block feature is not available: For intercom calls or calls received by call waiting. When a landline call (on cellular call) is being received during a landline call. When a landline call (or cellular call) is being received during a cellular call. Blocked calls are logged in the caller list. Block a single number manually Using the handset Press CALL BLOCK. Press the arrow up ▲ or down ▼ button to select "Block a single number" then press [SELECT]. Press [MENU]. Press the arrow up ▲ or down ▼ button to select "ADD" then press [SELECT]. Enter the phone number (24 digits max.). Press [SAVE], then press [OFF]. Using the Base Unit Press [CALL BLOCK]. Press the arrow up ▲ or down ▼ button to select "Block a single number" then press [SELECT]. Press [ADD]. Enter the phone number (24 digits max.). Press [SAVE], then press [EXIT]. View an example video of this programming on our YouTube Channel. The unit blocks calls that begin with a number stored in the call block list, such as a toll-free phone number prefix or certain area codes. From the Handset Press [CALL BLOCK]. Press the arrow up ▲ or down ▼ button to select "Block range of numbers", then press [SELECT]. Press [MENU]. Press the arrow up ▲ or down ▼ button to select "Add", then press [SELECT]. Enter the desired numbers (2-8 digits), example 1888 or 1800. Press [SAVE], then press [OFF]. From the Base Unit Press [CALL BLOCK]. Press the arrow up ▲ or down ▼ button to select "Block range of numbers", then press [SELECT]. Press [Add]. Enter the desired numbers (2 - 8 digits). Press [SAVE], then press [EXIT]. View an example of this programming on our YouTube Channel. You can block calls when no phone number is provided, such as private callers or out-of-area calls. From the Handset Press [CALL BLOCK]. Press the arrow up ▲ or down ▼ button to select "Block unknown CID", then press [SELECT]. Press the arrow up ▲ or down ▼ button to select the desired setting (ON/OFF), then press [SAVE]. Press [OFF]. From the Base Unit Press [CALL BLOCK]. Press the arrow up ▲ or down ▼ button to select "Block unknown CID", then press [SELECT]. Press the arrow up ▲ or down ▼ button to select the desired setting (ON/OFF), then press [SAVE]. Press [EXIT]. View the Operating Manual for KX-TG113CSK for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TG153CSK for more Call Block features. Single phone numbers can be stored in the call block list up to 60 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. You can block calls when no phone number is provided, such as private callers or out-of-area calls. Using the Handset Examples of Menu Button Location Press [MENU # 2 4 0]. Press the arrow up ▲ or down ▼ button to select the desired setting (ON/OFF), then press [SAVE]. Press [OFF]. View the Operating Manual for KX-TG163CSK for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. Block a single number manually Using the handset Press CALL BLOCK . Press the arrow up ▲ or down ▼ button to select " Block a single number " then press [SELECT]. Press [MENU]. Press the arrow up ▲ or down ▼ button to select " ADD " then press [SELECT]. Enter the phone number (24 digits max.) Press [SAVE], then press [OFF]. Using the Base Unit Press [MENU # 2 1 7]. Press the arrow up ▲ or down ▼ button to select " Block a single # " then press [SELECT]. Press [ADD]. Enter the phone number (24 digits max.). Press [SAVE], then press [EXIT]. View an example video of this programming on our YouTube Channel. You can block calls when no phone number is provided, such as private callers or out-of-area calls. From the Handset Press [CALL BLOCK]. Press the arrow up ▲ or down ▼ button to select " Block range of numbers " then press [SELECT]. Press [MENU]. Press the arrow up ▲ or down ▼ button to select " ADD " then press [SELECT]. Enter the desired numbers (2 - 8 digits). Press [SAVE], then press [OFF]. Using the Base Unit Press [MENU # 2 1 7]. Press the arrow up ▲ or down ▼ button to select " Block range of # " then press [SELECT]. Press [ADD]. Enter the desired numbers (2 - 8 digits). Press [SAVE], then press [EXIT]. View an example video of this programming on our YouTube Channel. You can block calls when no phone number is provided, such as private callers or out-of-area calls. From the Handset Press [CALL BLOCK]. Press the arrow up ▲ or down ▼ button to select the desired setting (ON/OFF), then press [SAVE]. Press [OFF]. From the Base Unit Press [MENU # 2 4 0]. Press the arrow up ▲ or down ▼ button to select the desired setting (ON/OFF), then press [SAVE], then press [EXIT]. View the Operating Manual for KX-TG175CSK for more Call Block features. You can store up to 50 phone numbers in the call block list We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. Block a single number manually You can press the [CALL BLOCK] button in the following situations to disconnect the current call and add a phone number to the call block list: When an incoming call is being received. When an incoming call is being received by the answering system. When talking on an outside call. Once a phone number has been added to the call block list, the unit will block calls from that phone number in the future. Press the [CALL BLOCK] button. The call block number is stored in the call block list and " Blocked caller " is displayed for about 7 seconds, then the call is disconnected. Block a single number manually You can store up to 20 phone numbers in the block list. To activate this feature, Block mode must be turned on. How to turn Block mode on or off. Press the [CALL BLOCK] button. Press the arrow down ▼ to select " Block List ". Press the [OK] button. "Block mode is displayed, press the [OK] button. Press the arrow up ▲ or down ▼ to select " On " or " Off ". Press the [OK] button to save. To exit programming. If programming with the base unit press [EXIT/STOP] Block a single number manually. Press the [CALL BLOCK] button. Press the arrow down ▼ to select " Block List ". Press the [OK] button. Block mode is displayed, press the [OK] button. Press the arrow up ▲ or down ▼ button to select the next available slot shown. Press the [OK] button. Enter in the telephone number or prefix that you want to block. Prefix example 1-800. Press the [OK] button to save. To exit programming. If programming with the base unit press [EXIT/STOP] When you store a phone number in the block list, you will need to store the full number including the area code for the number to be blocked. You can block calls when no phone number is provided, such as Private, or Out of area calls Press the [CALL BLOCK]. " Unknown call " is displayed, press the [OK] button. Press the arrow up ▲ or down ▼ to select " On " or " Off ". Press the [OK] button to save. To exit programming. If programming with the handset press [OFF] If programming with the base unit press [EXIT/STOP] View the Operating Manual for KX-TG2153SK for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 30 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. Block a single number manually Using the handset Press CALL BLOCK . Press the arrow up ▲ or down ▼ button to select " Block a single number " then press [SELECT]. Press [MENU]. Press the arrow up ▲ or down ▼ button to select " ADD " then press [SELECT]. Enter the phone number (24 digits max.). Press [SAVE], then press [OFF]. View an example video of this programming on our YouTube Channel. The unit blocks calls that begin with a number stored in the call block list, such a toll-free phone number prefix or certain area codes. From the Handset Press [CALL BLOCK]. Press the arrow up ▲ or down ▼ button to select " Block range of numbers ", then press [SELECT]. Press [MENU]. Press the arrow up ▲ or down ▼ button to select " Add ", then press [SELECT]. Enter the desired numbers (2-8 digits), example 1888 or 1800. Press [SAVE], then press [OFF]. From the Handset Press [CALL BLOCK]. Press the arrow up ▲ or down ▼ button to select " Block unknown CID ", then press [SELECT]. Press the arrow up ▲ or down ▼ button to select the desired setting (ON/OFF), then press [SAVE]. Press [OFF]. View the Operating Manual for KX-TG2721CSK for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TG3634, KX-TG3645 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. Block a single number manually You can press the [Call Block] button in the following situations to disconnect the current call and add a phone number to the call block list: when an incoming call is being received. when an incoming call is being recorded by the answering system. when talking on an outside call. Once a phone number has been added to the call block list, the unit will block calls from that phone number in the future. Press the arrow down ▼ [Call Block] button under the situations shown above. Confirm the call block number and press [YES]. The call block number is stored in the call block list, "Caller blocked" is displayed, and then the call is disconnected. Note: If the call has no phone number, the call is blocked but it is not stored in the call block list. The call block feature is not available for intercom calls or calls received by call waiting. Blocked calls are logged in the caller list. Block a single number manually Press the arrow down ▼ (Call Block). Press the arrow up ▲ or down ▼ button to select " Block a single number ". Press [SELECT]. Press [MENU]. Press the arrow up ▲ or down ▼ button to select " Add ". Press [SELECT]. Enter the phone number (24 digits max.). Press [SAVE]. Press [OFF]. View an example of this programming on our YouTube Channel. Press the arrow down ▼ (Call Block). Press the arrow up ▲ or down ▼ button to select " Block range of numbers ". Press [SELECT]. Press [MENU]. Press the arrow up ▲ or down ▼ button to select " Add ". Press [SELECT]. Enter the phone number (2-8 digits). Press [SAVE]. Press [OFF]. Press the arrow down ▼ (Call Block). Press the arrow up ▲ or down ▼ button to select " Block unknown CID ". Press [SELECT]. Press the arrow up ▲ or down ▼ button to select the desired setting (ON/OFF), then press [SAVE]. Press [OFF]. View the Operating Manual for KX-TG3683 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 1000 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 100 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. Block a single number with the Call Block Button You can press the [CALL BLOCK] button in the following situations to disconnect the current call and add a phone number to the call block list: When an incoming call is being received. When an incoming call is being recorded by the answering system. (for models with a built-in answering machine) When talking on an outside call. Once a phone number has been added to the call block list, the unit will block calls from that phone number in the future. Press the [CALL BLOCK] button under the situations shown above. Confirm the call block number and press [YES]. The call block number is stored in the call block list, "Caller blocked" is displayed, and then the call is disconnected. Note: If the call has no phone number, the call is blocked but it is not stored in the call block list. The call block feature is not available for intercom calls or calls received by call waiting. When a landline call is being received during a landline call. when a landline call (or cellular call) is being received during landline call. when a landline call (or cellular call) is being received during cellular call. Block a single number manually Using the handset Press CALL BLOCK . Press the arrow up ▲ or down ▼ button to select " Block a single number " then press [SELECT]. Press [MENU]. Press the arrow up ▲ or down ▼ button to select " ADD " then press [SELECT]. Enter the phone number (24 digits max.). Press [SAVE], then press [OFF]. Using the Base Unit Press [CALL BLOCK]. Press the arrow up ▲ or down ▼ button to select " Block a single number " then press [SELECT]. Press [ADD]. Enter the phone number (24 digits max.). Press [SAVE], then press [EXIT]. View an example video of this programming on our YouTube Channel. The unit blocks calls that begin with a number stored in the call block list, such as a toll-free phone number prefix or certain area codes. From the Handset Press [CALL BLOCK]. Press the arrow up ▲ or down ▼ button to select " Block range of numbers ", then press [SELECT]. Press [MENU]. Press the arrow up ▲ or down ▼ button to select " Add ", then press [SELECT]. Enter the desired numbers (2-8 digits), example 1888 or 1800. Press [SAVE], then press [OFF]. From the Base Unit Press [CALL BLOCK]. Press the arrow up ▲ or down ▼ button to select " Block range of numbers ", then press [SELECT]. Press [Add]. Enter the desired numbers (2-8 digits). Press [SAVE], then press [EXIT]. You can block calls when no phone number is provided, such as private callers or out of area calls. From the Handset Press [CALL BLOCK]. Press the arrow up ▲ or down ▼ button to select " Block unknown CID ", then press [SELECT]. Press the arrow up ▲ or down ▼ button to select the desired setting (ON/OFF), then press [SAVE]. Press [OFF]. From the Base Unit Press [CALL BLOCK]. Press the arrow up ▲ or down ▼ button to select " Block unknown CID ", then press [SELECT]. Press the arrow up ▲ or down ▼ button to select the desired setting (ON/OFF), then press [SAVE], then press [EXIT]. View the Operating Manual for KX-TG113CSK for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TG133CSK for more Call Block features. Single phone numbers can be stored in the call block list up to 60 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. You can block calls when no phone number is provided, such as private callers or out-of-area calls. Using the Handset Examples of Menu Button Location Press [MENU # 2 1 7]. Press the arrow up ▲ or down ▼ button to select the desired setting (ON/OFF), then press [SAVE]. Press [OFF]. View an example video of this programming on our YouTube Channel. You can block calls when no phone number is provided, such as private callers or out-of-area calls. Using the Handset Examples of Menu Button Location Press [MENU # 2 4 0]. Press the arrow up ▲ or down ▼ button to select the desired setting (ON/OFF), then press [SAVE]. Press [OFF]. Using the Base Unit Press [MENU # 2 1 7]. Press the arrow up ▲ or down ▼ button to select the desired setting (ON/OFF), then press [SAVE]. Press [EXIT]. View the Operating Manual for KX-TG163CSK for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. Block a single number manually Using the handset CALL BLOCK . Press the arrow up ▲ or down ▼ button to select " Block a single number " then press [SELECT]. Press [MENU]. Press the arrow up ▲ or down ▼ button to select " ADD " then press [SELECT]. Using the Base Unit Press [MENU # 2 1 7]. Press the arrow up ▲ or down ▼ button to select " Block range of # " then press [SELECT]. Press [SELECT]. Press [ADD]. Enter the desired numbers (2 - 8 digits). Press [SAVE], then press [EXIT]. View an example video of this programming on our YouTube Channel. You can block calls when no phone number is provided, such as private callers or out of area calls. From the Handset Press [CALL BLOCK]. Press the arrow up ▲ or down ▼ button to select the desired setting (ON/OFF), then press [SAVE]. Press [OFF]. From the Base Unit Press [MENU # 2 4 0]. Press the arrow up ▲ or down ▼ button to select the desired setting (ON/OFF), then press [SAVE], then press [EXIT]. View the Operating Manual for KX-TG175CSK for more Call Block features. You can store up to 50 phone numbers in the call block list. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. Block a single number manually You can press the [CALL BLOCK] button in the following situations to disconnect the current call and add a phone number to the call block list: When an incoming call is being received by the answering system. When talking on an outside call. Once a phone number has been added to the call block list, the unit will block calls from that phone number in the future. Press the [CALL BLOCK] button. The call block number is stored in the call block list and " Blocked caller " is displayed for about 7 seconds, then the call is disconnected. Block a single number manually You can store up to 20 numbers in the block list. To activate this feature, Block mode must be turned on. How to turn Block mode on or off. Press the [CALL BLOCK] button. Press the arrow down ▼ to select " On " or " Off ". Press [OK] button to save. To exit programming. If programming with the base unit press [EXIT/STOP] If programming with the base unit press [EXIT/STOP] Block a single number manually. Press the [CALL BLOCK] button. Press the arrow down ▼ to select " Block number ". Press the [OK] button. If required press the arrow up ▲ or down ▼ button to select the next available slot. Press the [OK] button. Enter in the telephone number or prefix that you want to block. Prefix example 1-800. Press the [OK] button to save. To exit programming. If programming with the handset press [OFF] If programming with the base unit press [EXIT/STOP] When you store a phone number in the block list, you will need to store the full number including the area code for the number to be blocked. You can block calls when no phone number is provided, such as, Private, or Out of area calls Press the [CALL BLOCK] button. " Unknown call " is displayed, press the [OK] button. Press the arrow up ▲ or down ▼ to select " On " or " Off ". Press the [OK] button to save. To exit programming. If programming with the handset press [OFF] If programming with the base unit press [EXIT/STOP] View the Operating Manual for KX-TG2153SK for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 30 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. Block a single number manually Using the handset Press CALL BLOCK . Press the arrow up ▲ or down ▼ button to select " Block a single number " then press [SELECT]. Press [MENU]. Press the arrow up ▲ or down ▼ button to select " ADD " then press [SELECT]. Enter the phone number (24 digits max.). Press [SAVE], then press [OFF]. View an example video of this programming on our YouTube Channel. The unit blocks calls that begin with a number stored in the call block list, such as a toll-free phone number prefix or certain area codes. From the Handset Press [CALL BLOCK]. Press the arrow up ▲ or down ▼ button to select " Block range of numbers ", then press [SELECT]. Press [MENU]. Press the arrow up ▲ or down ▼ button to select the desired setting (ON/OFF), then press [SAVE]. Press [OFF]. View the Operating Manual for KX-TG27CSK for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TG3634, KX-TG3645 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. Block a single number manually You can press the [Call Block] button in the following situations to disconnect the current call and add a phone number to the call block list: when an incoming call is being received. when an incoming call is being recorded by the answering system. when talking on an outside call. Once a phone number has been added to the call block list, the unit will block calls from that phone number in the future. Press the [CALL BLOCK] button under the situations shown above Confirm the call block number and press [YES]. The call block number is stored in the call block list, "Caller blocked" is displayed, and then the call is disconnected. Note: If the call has no phone number, the call is blocked but it is not stored in the call block list. The call block feature is not available for intercom calls or calls received by call waiting. Blocked calls are logged in the caller list. Block a single number manually Press the arrow down ▼ (Call Block). Press the arrow up ▲ or down ▼ button to select " Block a single number ". Press [SELECT]. Press [MENU]. Press the arrow up ▲ or down ▼ button to select " Add ". Press [SELECT]. Enter the phone number (24 digits max.). Press [SAVE], then press [OFF]. View an example video of this programming on our YouTube Channel. The unit blocks calls that begin with a number stored in the call block list, such as a toll-free phone number prefix or certain area codes. From the Handset Press [CALL BLOCK]. Press the arrow up ▲ or down ▼ button to select " Block range of numbers ", then press [SELECT]. Press [MENU]. Press the arrow up ▲ or down ▼ button to select " Add ", then press [SELECT]. Enter the desired numbers (2-8 digits), example 1888 or 1800. Press [SAVE], then press [OFF]. From the Handset Press [CALL BLOCK]. Press the arrow up ▲ or down ▼ button to select " Block unknown CID ", then press [SELECT]. Press the arrow up ▲ or down ▼ button to select the desired setting (ON/OFF), then press [SAVE]. Press [OFF]. View the Operating Manual for KX-TG3834 for more Call Block features. You can store up to 250 phone numbers in the call block list. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. Block a single number manually Using the handset Examples of Menu Button Location Press [MENU # 2 1 7]. Press [MENU]. Press the arrow up ▲ or down ▼ button to select " Add " then press [SELECT]. Press [ADD]. Enter the phone number (24 digits max.). Press [SAVE], then press [OFF]. Using the Base Unit Press [MENU # 2 1 7], then press [OFF]. Using the Base Unit Press [MENU # 2 1 7]. Press [MENU]. Press the arrow up ▲ or down ▼ button to select " ADD " then press [SELECT]. Enter the phone number (24 digits max.). Press [SAVE], then press [EXIT]. View an example video of this programming on our YouTube Channel. You can block calls when no phone number is provided, such as private callers or out of area calls. Using the Base Unit Examples of Menu Button Location Press [MENU # 2 4 0]. Press the arrow up ▲ or down ▼ button to select the desired setting (ON/OFF), then press [SAVE]. Press [OFF]. View the Operating Manual for KX-TG385SK for more Call Block features. View the Operating Manual for KX-TG395CSK/SK for more Call Block features. You can store up to 30 phone numbers in the call block list. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. Block a single number manually. Using the handset Examples of Menu Button Location Press [MENU # 2 4 0]. Press the arrow up ▲ or down ▼ button to select the desired setting (ON/OFF), then press [SAVE]. Press [OFF]. Using the Base Unit Press [MENU # 2 1 7]. Press the arrow up ▲ or down ▼ button to select " Add " then press [SELECT]. Enter the phone number (24 digits max.). Press [SAVE], then press [OFF]. View an example video of this programming on our YouTube Channel. Block a single number manually. Using the handset Examples of Menu Button Location Press [MENU # 2 1 7]. Press [MENU]. Press the arrow up ▲ or down ▼ button to select " Add " then press [SELECT]. Enter the phone number (24 digits max.). Press [SAVE], then press [OFF]. View an example video of this programming on our YouTube Channel. View the Operating Manual for KX-TG432SK for more Call Block features. View the Operating Manual for KX-TG433CSK/SK for more Call Block features. You can store up to 60 phone numbers in the call block list. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TG443CSK, KX-TG443SK for more Call Block features. View the Operating Manual for KX-TG444SK for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. Block a single number manually Using the handset Examples of Menu Button Location [MENU # 2 1 7]. Press the arrow up ▲ or down ▼ button to select " Block a single number " then press [SELECT]. Press [MENU]. Press the arrow up ▲ or down ▼ button to select " ADD " then press [SELECT]. Enter the phone number (24 digits max.). Press [SAVE], then press [EXIT]. View an example video of this programming on our YouTube Channel. You can block calls when no phone number is provided, such as private callers or out-of-area calls. Using the handset Examples of Menu Button Location Press [MENU # 2 4 0]. Press the arrow up ▲ or down ▼ button to select the desired setting (ON/OFF), then press [SAVE]. Press [OFF]. View the Operating Manual for KX-TG454SK, KX-TG465CSK for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TG472SK, KX-TG473SK for more Call Block features. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TG484SK for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TG572SK, KX-TG573SK for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TG583SK for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TG6145SK for more Call Block features. Phone numbers and ranges can be stored in the call block list up to 30 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TG633SK for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 150 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TG684SK, KX-TG6848SK for more Call Block features. You can store up to 30 phone numbers in the call block list. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TG6591, KX-TG6592 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TG674SK for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 150 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TG684SK for more Call Block features. You can store up to 30 phone numbers in the call block list. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TG7122SK for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 150 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TG784 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. Block a single number manually Using the handset Press CALL BLOCK . Press the arrow up ▲ or down ▼ button to select " Block a single number " then press [SELECT]. Press [MENU]. Press the arrow up ▲ or down ▼ button to select " ADD " then press [SELECT]. Enter the phone number (24 digits max.). Press [SAVE], then press [OFF]. Using the Base Unit Press [CALL BLOCK]. Press the arrow up ▲ or down ▼ button to select " Block a single # " then press [SELECT]. Press [ADD]. Enter the phone number (24 digits max.). Press [SAVE], then press [EXIT]. View an example video of this programming on our YouTube Channel. The unit blocks calls that begin with a number stored in the call block list, such as a toll-free phone number prefix or certain area codes. From the Handset Press [CALL BLOCK]. Press the arrow up ▲ or down ▼ button to select " Block range of numbers ", then press [SELECT]. Press [MENU]. Press the arrow up ▲ or down ▼ button to select " ADD " then press [SELECT]. Enter the desired numbers (2-8 digits). Press [SAVE], then press [OFF]. From the Base Unit Press [CALL BLOCK]. Press the arrow up ▲ or down ▼ button to select " Block range of # " then press [SELECT]. Press [Add]. Enter the desired numbers (2-8 digits), example 1888 or 1800. Press [SAVE], then press [EXIT]. View an example video of this programming on our YouTube Channel. View the Operating Manual for KX-TG7785SK for more Call Block features. You can store up to 250 phone numbers in the call block list. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TG787 for more Call Block features. You can store up to 30 phone numbers in the call block list. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TG832SK, KX-TG833SK for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 150 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TG885SK for more Call Block features. You can store up to 250 phone numbers in the call block list. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TG955 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 1000 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TG985SK for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 2000 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. Block a single number manually Using the handset Press CALL BLOCK . Press the arrow up ▲ or down ▼ button to select " Single # " then press [SELECT]. Press [ADD]. Enter the phone number (24 digits max.). Press [SAVE], then press [EXIT]. View an example video of this programming on our YouTube Channel. Using the Base Unit Press [CALL BLOCK]. Press the arrow up ▲ or down ▼ button to select " Single # " then press [SELECT]. Press [ADD]. Enter the phone number (24 digits max.). Press [SAVE], then press [EXIT]. View an example video of this programming on our YouTube Channel. The unit blocks calls that begin with a number stored in the call block list, such as a toll-free phone number prefix or certain area codes. From the Handset Press [CALL BLOCK]. Press the arrow up ▲ or down ▼ button to select " Range of # ", then press [SELECT]. Press [Add]. Enter the desired numbers (2-8 digits). Press [SAVE], then press [EXIT]. View an example video of this programming on our YouTube Channel. View the Operating Manual for KX-TG994SK for more Call Block features. You can store up to 20 telephone numbers in the block list. To activate this feature, Block mode must be turned on. How to turn Block mode on or off. Press the [MENU/OK] button. Press the arrow down ▼ to select " Block list ". Press the [MENU/OK] button. " Block mode " is displayed. Press the [MENU/OK] button. Press the arrow up ▲ or down ▼ to select " On " or " Off ". Press the [MENU/OK] button to save. How to store a single telephone number to the Block list. Press the [MENU/OK] button. Press the arrow down ▼ to select " Block list ". Press the [MENU/OK] button. Press the arrow down ▼ to select " Advanced setting ". Press the [MENU/OK] button. Press the arrow up ▲ or down ▼ to select " Call block ". Press the [MENU/OK] button. If required press the arrow up ▲ or down ▼ button to select the next available slot. Press the [MENU/OK] button. Enter in the telephone number that you want to block. Press the [MENU/OK] button to save. When you store a phone number in the block list, you will need to store the full number including the area code for the number to be blocked. To switch anonymous call on or off. You can block calls when no phone number is provided, such as Private, or Out of area calls Press the [MENU/OK] button. " Anonymous call " is displayed. Press the [MENU/OK] button. Press the arrow up ▲ or down ▼ to select " On " or " Off ". Press the [MENU/OK] button to save. How to store the next available Block list slot. Press the arrow down ▼ to select the next available Block list slot then press the [MENU/OK] button. The telephone number is displayed, press the [MENU/OK] button again to confirm. Note - To activate this feature, Block mode must be turned on. Use the Operating Manual for KX-TGB81 for more Call Block features. You can store up to 50 phone numbers in the call block list. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGB85 for more Call Block features. You can store up to 30 phone numbers in the call block list. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGC21, KX-TGC22, KX-TGC253 for more Call Block features. You can store up to 30 phone numbers in the call block list. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for more Call Block features. You can store up to 30 phone numbers in the call block list. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGC35, KX-TGC36 for more Call Block features. View the Operating Manual for KX-TGC38 for more Call Block features. You can store up to 60 phone numbers in the call block list. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGD21, KX-TGD22 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 60 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGD39 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 150 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGD43 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 150 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGD51, KX-TGD53 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 150 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGD56, TGD58 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 150 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGD59 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 150 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGD61, KX-TGD63 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 150 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGD66 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 1000 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 1000 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGD86 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 1000 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. Block a single number manually Using the handset Press CALL BLOCK . Press the arrow up ▲ or down ▼ button to select " Single number " then press [SELECT]. Press [MENU]. Press the arrow up ▲ or down ▼ button to select " ADD " then press [SELECT]. Enter the phone number (24 digits max.). Press [SAVE], then press [OFF]. View an example video of this programming on our YouTube Channel. The unit blocks calls that begin with a number stored in the call block list, such as a toll-free phone number prefix or certain area codes. From the Handset Press [CALL BLOCK]. Press the arrow up ▲ or down ▼ button to select " Range of numbers ", then press [SELECT]. Press [MENU]. Press the arrow up ▲ or down ▼ button to select " ADD " then press [SELECT]. Enter the desired numbers (2-8 digits), example 1888 or 1800. Press [SAVE], then press [OFF]. View an example video of this programming on our YouTube Channel. View the Operating Manual for KX-TGD890, KX-TGD892 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGE21, KX-TGE23, KX-TGE24 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGE26, KX-TGE27 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGE43, KX-TGE445 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 150 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGE46, KX-TGE47, KX-TGE48 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 1000 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGE63, KX-TGE64 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 1000 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGE66, KX-TGE67 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be

blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGF34 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGF35 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGF37 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGF54 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGF57 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 1000 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. Block a single number manually. Using the Handset Press CALL BLOCK . Press the arrow up ▲ or down ▼ button to select " Call block " then press [SELECT]. Press the arrow up ▲ or down ▼ button to select " Block a single number " then press [SELECT]. Press [MENU]. Press the arrow up ▲ or down ▼ button to select " ADD " then press [SELECT]. Enter the phone number (24 digits max.). Press [SAVE], then press [OFF]. Using the Base Unit Press CALL BLOCK . Press the arrow up ▲ or down ▼ button to select " Call block " then press [SELECT]. Press the arrow up ▲ or down ▼ button to select " Block a single # " then press [SELECT]. Press [ADD]. Enter the phone number (24 digits max.). Press [SAVE], then press [Exit]. Block a range of numbers. The unit blocks calls that begin with a number stored in the call block list, such as a toll-free phone number prefix or certain area codes. From the Handset Press [CALL BLOCK]. Press the arrow up ▲ or down ▼ button to select " Call block " then press [SELECT]. Press the arrow up ▲ or down ▼ button to select " Block range of numbers ", then press [SELECT]. Press [MENU]. Press the arrow up ▲ or down ▼ button to select " Add ", then press [SELECT]. Enter the desired numbers (2-8 digits), example 1888 or 1800. Press [SAVE], then press [OFF]. Using the Base Unit Press CALL BLOCK . Press the arrow up ▲ or down ▼ button to select " Block a range of # " then press [SELECT]. Press [ADD]. Enter the desired numbers (208 digits). Press [SAVE], then press [Exit]. View an example video of this programming on our YouTube Channel. You can block calls when no phone number is provided, such as private callers or out of area calls. From the Handset Press [CALL BLOCK]. Press the arrow up ▲ or down ▼ button to select " Call block " then press [SELECT]. Press the arrow up ▲ or down ▼ button to select " Block unknown CID ", then press [SELECT]. Press the arrow up ▲ or down ▼ button to select the desired setting (ON/OFF), then press [SELECT]. Press [OFF]. View the Operating Manual for KX-TGF675 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 1000 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGF77 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 1000 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGF87 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 1000 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. Block a single number manually Using the handset Press CALL BLOCK . Press the arrow up ▲ or down ▼ button to select " Call block " then press [SELECT]. Press [ADD]. Enter the phone number (24 digits max.). Press [SAVE], then press [EXIT]. View an example video of this programming on our YouTube Channel. The unit blocks calls that begin with a number stored in the call block list, such as a toll-free phone number prefix or certain area codes. From the Handset Press [CALL BLOCK]. Press the arrow up ▲ or down ▼ button to select " Block range of numbers ", then press [SELECT]. Press [ADD]. Enter the desired numbers (2-8 digits). Press [SAVE], then press [EXIT]. View an example video of this programming on our YouTube Channel. You can block calls when no phone number is provided, such as private callers or out of area calls. From the Handset Press [CALL BLOCK]. Press the arrow up ▲ or down ▼ button to select " Block unknown CID ", then press [SELECT]. Press the arrow up ▲ or down ▼ button to select the desired setting (ON/OFF), then press [SAVE]. Press [OFF]. From the Base Unit Press [CALL BLOCK]. Press the arrow up ▲ or down ▼ button to select " Block unknown CID ", then press [SELECT]. Press the arrow up ▲ or down ▼ button to select the desired setting (ON/OFF), then press [SAVE]. Press [EXIT]. View the Operating Manual for KX-TG113CSK for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 2000 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGF944 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 2000 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGF973 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 2000 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGF975 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGL43 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. Block a single number with the Call Block Button You can press the arrow down ▼ (Call Block) button in the following situations to disconnect the current call and add a phone number to the call block list: when an incoming call is being received. when an incoming call is being recorded by the answering system. When talking on an outside call. Once a phone number has been added to the call block list, "Caller blocked" is displayed, and then the call is disconnected. Note: If the call has no phone number, the call is blocked but it is not stored in the call block list. The call block feature is not available for intercom calls or calls received by call waiting. when a landline call is being received during landline call. When a landline call (or cellular call) is being received during a cellular call. Blocked calls are logged in the caller list. View the Operating Manual for KX-TGL46 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. Block a single number with the Call Block Button You can press the [BLOCK] button in the following situations to disconnect the current call and add a phone number to the call block list: When an incoming call is being received When an incoming call is being recorded by the answering system. When talking on an outside call. Once a phone number has been added to the call block list, the unit will block calls from that phone number in the future. When an outside call is being received, or When an incoming call is being recorded by the answering system. Press the [BLOCK] button on the handset. Confirm the call block number and press [YES]. Note: If the call has no phone number, the call is blocked but it is not stored in the call block list. The call block feature is not available for intercom calls or calls received by call waiting. Blocked calls are logged in the caller list. View the Operating Manual for KX-TG422 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 1000 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. View the Operating Manual for KX-TGH26 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. Block a single number with the Call Block Button You can press the arrow down ▼ (Call Block) button in the following situations to disconnect the current call and add a phone number to the call block list: when an incoming call is being received. when an incoming call is being recorded by the answering system. When talking on an outside call. Once a phone number has been added to the call block list, the unit will block calls from that phone number in the future. Press the arrow down ▼ (Call Block) button under the situations shown above. Confirm the call block number and press [YES]. Note: If the call has no phone number, the call is blocked but it is not stored in the call block list. The call block feature is not available for intercom calls or calls received by call waiting. Press [MENU]. Press the arrow up ▲ or down ▼ button to select " Block unknown CID " then press [SELECT]. Press the arrow up ▲ or down ▼ button to select the desired setting (ON/OFF). Press [SAVE], then press [OFF]. View the Operating Manual for KX-TGM420, KX-TGM450 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Block a single number with the Call Block Button You can press the [BLOCK] button in the following situations to disconnect the current call and add a phone number to the call block list: When an incoming call is being received When an incoming call is being recorded by the answering system. When talking on an outside call. Once a phone number has been added to the call block list, the unit will block calls from that phone number in the future. When an outside call is being received, or When an incoming call is being recorded by the answering system. Press the [BLOCK] button on the handset. Confirm the call block number and press [YES]. The call block feature is not available for intercom calls received by call waiting. when a landline call is being received during landline call. when a landline call (or cellular call) is being received during a cellular call. Blocked calls are logged in the caller list. View the Operating Manual for KX-TGM430 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 1000 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. Block a single number manually Using the handset Press CALL BLOCK . Press the arrow up ▲ or down ▼ button to select " Single number " then press [SELECT]. Press [ADD]. Enter the phone number (24 digits max.). Press [SAVE], then press [OFF]. View the Operating Manual for KX-TGM470, KX-TGM490 for more Call Block features. Single phone numbers and ranges of numbers can be stored in the call block list up to 250 items in total. We recommend storing 10 digits (including the area code). If only 7 digits are stored, all numbers that have the same last 7 digits will be blocked. Select a Block Option to view programming. Block a single number manually Using the handset Press CALL BLOCK . Press the arrow up ▲ or down ▼ button to select " Single number " then press [SELECT]. Press [ADD]. Enter the phone number (24 digits max.). Press [SAVE], then press [OFF]. View the Operating Manual for more Call Block features.

Unblocking Blocked Numbers on Panasonic Phone: A Step-by-Step Guide Panasonic phones are known for their sleek designs and advanced features, but one of the most frustrating aspects of owning a Panasonic phone is dealing with blocked numbers. Whether it's a telemarketer, a spammer, or a friend who accidentally blocked you, blocked numbers can be a real nuisance. In this article, we'll provide you with a comprehensive guide on how to unblock all blocked numbers on your Panasonic phone. Understanding Blocked Numbers Before we dive into the solution, it's essential to understand what blocked numbers are. Blocked numbers are phone numbers that have been marked as spam or unwanted by the phone's operating system. These numbers are often used by scammers, telemarketers, and spammers to contact you repeatedly. Unblocking blocked numbers means removing these unwanted numbers from your phone's contact list. Why Unblock Blocked Numbers? Unblocking blocked numbers is crucial for several reasons: Prevent spam calls: By unblocking blocked numbers, you can prevent unwanted calls and reduce the risk of receiving spam messages. Improve phone performance: Blocking unwanted numbers can help improve your phone's performance by reducing the number of calls and texts you receive. Enhance your phone's security: Unblocking blocked numbers can also help protect your phone's security by reducing the risk of malware and other online threats. How to Unblock Blocked Numbers on Panasonic Phone Panasonic phones have a built-in feature to unblock blocked numbers. Here's how to do it: Step 1: Open the Phone Settings On your Panasonic phone, go to the Settings app. Scroll down and select Phone. Tap on Blocked numbers. Step 2: Add Blocked Numbers Tap on Add blocked number. Enter the blocked number in the format XXX-XXX-XXXX. Tap on Add. Step 3: Remove Blocked Numbers To remove a blocked number, tap on Remove. Confirm that you want to remove the number. Additional Tips Use the Phone's Built-in Spam Filter: Panasonic phones have a built-in spam filter that can help reduce the number of spam calls. To activate the spam filter, go to the Settings app and select Phone. Scroll down and select Spam filter. Enable the spam filter and set the Spam filter sensitivity to High. Use a Third-Party App: There are several third-party apps available that can help you unblock blocked numbers on your Panasonic phone. Some popular options include Spam Filter, Blocked Numbers, and Call Filter. Regularly Update Your Phone's Software: Keeping your phone's software up to date can help improve the spam filter and reduce the number of blocked numbers. Table: Unblocking Blocked Numbers on Panasonic Phone Feature Description Blocked Numbers A built-in feature that allows you to add and remove blocked numbers from your phone's contact list. Add Blocked Number To add a blocked number to your phone's contact list. Enter the blocked number in the format XXX-XXX-XXXX and tap on Add. Remove Blocked Number To remove a blocked number from your phone's contact list. Tap on Remove and confirm that you want to remove the number. Spam Filter A built-in feature that can help reduce the number of spam calls. To activate the spam filter, go to the Settings app and select Phone. Scroll down and select Spam filter. Enable the spam filter and set the Spam filter sensitivity to High. Third-Party Apps Several third-party apps available that can help you unblock blocked numbers on your Panasonic phone. Some popular options include Spam Filter, Blocked Numbers, and Call Filter. Conclusion Unblocking blocked numbers on your Panasonic phone is a simple process that can help improve your phone's performance, prevent spam calls, and enhance your phone's security. By following the steps outlined in this article, you can easily unblock all blocked numbers on your Panasonic phone. Remember to regularly update your phone's software and use a third-party app to help you unblock blocked numbers. Your friends have asked us these questions - Check out the answers!