Click Here

This RCA RCR414BHE Remote Codes List for the Platinum Pro Universal Remote Control will help you to easily program all of your devices. The RCA RCR414BHE Platinum Pro 4-Device Universal Remote Control works with all of the major brands and devices. This remote will even work with the latest streaming players by using a separate key. This Universal Remote Control will operate up to 4 devices such as: TV's Streaming Players Satellite or Cable Box DVD or Blu-Ray Players RCA RCR414BHE Platinum Pro Universal Remote Control Instruction Manual and User's Guide This Instruction Manual will walk you through how to program your devices by using the codes from the Code List that is also included below. You will need this guide to program your remote to its full potential. It will allow you to set up your remote to use 4 different devices from all the major brands. Access the RCA RCR414BHE User's Guide and Instruction Manual Here: RCA RCR414BHE Platinum Pro Universal Remote Control Code List Using this code list you can find the correct code for each of your devices. This will allow you to program 4 different types and brands of equipment. This code list will be needed along with the User's Manual to correctly program each of your devices. Find the RCA RCR414BHE Code List Here: Click Here for More RCA User Manuals and Code Lists Losing or damaging your original TV remote can be incredibly frustrating. Thankfully, a universal remote control offers a powerful and convenient solution to manage all your entertainment devices from a single unit. When talking about universal remotes, RCA universal remote controls are quite popular in the market. Today, we will be taking a look at RCA Universal Remote Codes and detailed, step-by-step instructions on how to program your RCA remote for any device. RCA Universal Remotes are designed to control multiple devices, including TV, DVD, VCR, Cable, Satellite, and other devices. Some models are even capable of controlling up to eight devices. Quick Answer: How to Program Your RCA Universal Remote with Auto-Search Feature Turn on your TV manually. Hold the TV button + Power button together until the red light stays on. Press Play every 5 seconds until the TV turns off. Press Reverse every 2 seconds until the TV turns back on. Press Stop to save the code. Tip: If this method doesn't work, refer to the "How to Program RCA Universal Remote with Codes" section below. Admiral: 0463, 4030, 4111, 4221, 10093, 10463 Advent: 1570, 10761 Affinity: 3717, 3577, 3870 Aiwa: 1362 Akai: 1675, 11675, 10702, 10672 AOC: 1589, 3720, 1365, 2014, 2087, 4101, 11365, 11589, 12014, 12087 Apex Digital: 2397, 4347, 4350, 10156, 10748, 10767, 12397 Ario: 2397 Astar: 11738 Asus: 3340 Atvio: 3638, 3636, 3657 Audiovox: 1564, 1769, 0623, 10451, 10802, 10846, 10875, 11937, 11951, 11952 Auria: 2087, 2014, 2277 Aventura: 0171, 10171 Avol: 3118 Axion: 11937 BGH: 4029, 4070, 0898, 2414, 0876, 4028, 4030 Blue Sky: 3997 Britania: 2414 Broksonic: 0463, 1892, 10463 Carver: 10054 CCE: 3782, 4091, 0623, 4092 Celebrity: 10000 Champion: 1362 Changhong: 3814 Coby: 3478, 3627, 2344, 12306, 12315, 12340, 12343, 12344, 12345, 12347, 12348, 12350 Commercial Solutions: 1447, 11447, 10047 Contex: 4053 Continental: 2357 Coradir: 2844 Craig: 3423 Crosley: 10000, 10054 Crown Mustang: 0898 Curtis: 2855, 3577, 3895, 2352, 2397, 4035, 4053, 3636, 1326, 3382, 3717, 12352 Curtis Mathes: 0623, 10047, 10054, 10451, 10093, 10702, 10145, 11661, 11147, 11347 Cytron: 1326 Daewoo: 0623, 10451, 11661, 10661, 10672 Dell: 11264, 11080, 11863 Denon: 10145 Digitrex: 4207 Dish Network: 11948 Disney: 1892, 0171, 11892, 81017 Dumont: 0017, 10017 Durabrand: 0463, 0171, 1570, 0178, 10463, 10178, 10171, 11034 Dynex: 2049, 2184, 11463, 11785, 11810, 12049, 12184 Electroband: 10000 Electrograph: 11755 Electrohome: 0463, 1570, 1670, 10463 Electron: 2855 Elektra: 0017, 0623 Element: 3559, 1687, 2183, 2964, 1886, 11886, 12183, 01815, 70017, 81918, 45112, 72015, 34211, 79517, 24912, 34611 Elite: 1457 Emerson: .1864, 1394, 0171, 1886, 0463, 1963, 0178, 0623, 3623, 2183, 3559, 11864, 10017, 10451, 10463, 10178, 10171, 11661, 11394, 11944, 11963 Emprex: 11422 Encross: 0876 Envision: 1589, 1365, 2087, 2014, 10813, 11365, 11589, 12014, 12087 Epworth: 1362 EQD: 2014, 2087, 2277 ESA: 0171, 1963, 10171, 11944, 11963 Fair Mate: 1326 Favi: 3382 Fisher: 1362 Fluid: 2964, 3559, 12964, 70013 Fujitsu: 10809 Funai: 1864, 0171, 1394, 1963, 10000, 10171, 11271, 11963 Gateway: 11755, 11756 GE: 1447, 0178, 11447, 10047, 10451, 10178, 11347 GFM: 0171, 1963, 1886, 1864, 10171, 11886, 11963, 12167 Gibraltar: 0017, 10017 Go Video: 10886 GoldStar: 0178, 10178 Haier: 1749, 2309, 1748, 3382, 2293,4398, 1570, 11034, 11748, 11749, 12309 Hallmark: 0178, 10178 Hannspree: 1348, 11348, 11745 Harman/Kardon: 10054 Havermy: 10093 H-Buster: 3620, 3419 Helios: 10865 Hello Kitty: 10451 Hewlett Packard: 11494, 11502 Hisense: 13519, 14740, 14618, 12183, 15156, 15176, 15185, 14656, 11660, 11314, 11756, 13382, 14487, 35611, 44211, 67614, 78115, 59413, 3519, 2183, 4398, 3382, 4029, 10748, 12098, 12355, 12419 Hisense Roku: 44211, 55712 Hitachi: 1643, 3639, 3382, 3697, 11643, 11145, 10679, 10145 Hiteker: 3118 HP: 11494, 11502 Hyundai: 4509 iLo: 0171, 1394, 11394, 11684, 11990 Infinity: 10054 Initial: 11990 Insignia: 12049, 14487, 11780, 13227, 11564, 11326, 12184, 15213, 11892, 12002, 11423, 10171, 10463, 11385, 11660, 12751, 11756, 28911, 12219, 49412, 28511, 06919, 07216, 69212, 89713, 70017, 39512, 45013, 69613, 82615, 61312, 2049, 1564, 1326, 1892, 0171, 0463, 1963, 2184, 11204, 11517, 11810, 11963, 12049, 12417 Insignia Roku: 12219, 44211 Inteq: 0017, 10017 IRT: 0623 iSymphony: 3382, 3118, 3094 JBL: 10054 JCB: 10000 JC Penney: 0178, 0156 JCM: 2256, 12256 Jensen: 1326, 10761 JVC: 1774, 1601, 2321, 2271, 0463, 1570, 1670, 4070, 1892, 10463, 10053, 10731, 11253, 11601, 11774, 12271 KC: 4182 KDS: 1523, 1687, 11498 KLH: 10767 Ken Brown: 4056, 4099, 4221, 4444 Kreisen: 0876 Legend: 2397, 2309 Lexus: 3638, 3657 LG: 31311, 52412, 63913, 11840, 12731, 11860, 11423, 12358, 14397, 14398, 11756, 2731, 2358, 3397, 0178, 0017, 10017, 10178, 10856, 11447, 12424, 11265 LG Alps: 2358 LodgingStar: 3147 LXI: 0156, 0178, 0017, 10047, 10054, 10156, 10178 MAG: 1687, 1523, 11498 Magnavox: 3623, 1866, 2372, 1454, 2597, 1963, 0171, 1365, 1867, 11867, 11454, 10054, 10802, 11198, 11254, 11365, 11944, 11963, 11990, 11866, 12372, 10171, 10051 Marantz: 1454, 11454, 10054 Master-G: 3419 Matsushita: 10250 Maxent: 11755 Megatron: 0178, 10178, 10145 Memorex: 0463, 1570, 1670, 0178, 1892, 0171, 1687, 10463, 10150, 10178, 11892 MGA: 0178, 10178, 10150 Microsonic: 1326, 3419, 4235 Midland: 0017, 10047, 10017, 10051 Mintek: 11990 Miray: 3847, 2414, 2429, 3183, 4178, 0898 Misakai: 0171 Mitsubhishi: 11250, 10093, 10150, 10178, 11797 Mitsubishi Electric: 1250, 0178 Mitsui: .3658, 3638, 3657 Motorola: 10093 NAD: 0156, 0178, 10156, 11156, 10178 Naoki: 1540, 2357 Naxa: 2104, 3382, 3423, 12104, 82318, 11711, 25811, 29419, 41011 NEC: 0876, 2293, 11704, 11797 NetTV: 11755 New Acoustic Dimension: 0156, 0178 Nexus: 3519 Nexus Electronics: 2183, 12183 Nikko: 0178, 0017, 0156, 10178 Nimbro: 2104 Noblex: 1362, 3697, 1142, 4029, 3803, 4030, 4149, 4205 Norcent: 1365, 1589, 10748, 11365, 11589, 11745 Nordmende: 3419, 3861, 3134, 3327, 3767, 3835 NuVision: 4347 Ocosmo: 2337, 3899 Olevia: 1610, 11610, 11144, 11240, 11331 Onn: 14398, 15348, 11709, 11756, 13024, 13078, 15118 Onn Roku: 44211 Optimus: 10250 Optoma: 11348 Optonica: 10093 Orion: 0463, 1892, 3540, 10463, 11463 Panasonic: 1480, 1291, 0156, 0178, 10250, 11480, 11457, 11291, 10051, 11271, 11941, 11946 Panavox: 4149 PARK: 2104, 12104 Penney: 0178, 0156, 10047, 10156, 10178, 11347, 10051 Petters: 11523 Philco: 3426, 3022, 2414, 0171, 1963, 4178, 0623, 1394, 1142, 1362, 0463, 3639, 3697, 10054, 10171, 11271, 11394, 11963 Philips: 11867, 12372, 11454, 12374, 11866, 13623, 14365, 14398, 10054, 10171, 11755, 11365, 11394, 11756, 14740, 62414, 17419, 33412, 06918, 73915, 84416, 95017, 44211, 21319, 43911, 48111, 82615, 88518, 1867, 2372, 1454, 2597, 4222, 3623, 2800, 1744, 1866, 0017, 0171, 1963, 1365, 1394, 1589, 10690 Philips Roku: 44211 Pioneer: 1457, 11457, 10679, 11260 Planar: 1589, 11589, 40413, 75812 Polaroid: 1523, 1769, 4035, 1687, 1326, 1524, 11523, 10865, 11276, 11314, 11498, 11766, 12002, 12121 Portland: 0623, 10451, 11661 Prima: 1749, 10761, 11749, 11785 Proscan: 1447, 3577, 3382, 2183, 2256, 3717, 3332, 3636, 3895, 4035, 4053, 4483, 4495, 2746, 3559, 3953, 11447, 10047, 11347, 12147, 12183, 12256 Proton: 0178, 10178 Proview: 1687, 1523, 11498 Pulsar: 0017, 10017 QuantumFX: 2337 Quasar: 3899, 4207, 4367, 1291, 10250, 11291, 10051 RadioShack: 0178, 10178, 10047 RCA: 2746, 2932, 2434, 3577, 1447, 2247, 3382, 3717, 3332, 3895, 2187, 4053, 3636, 2183, 2855, 3147, 4394, 0623, 2429, 3419, 4035, 1670, 11547, 11447, 10047, 10093, 10679, 11047, 11147, 11247, 11347, 11781, 11948, 11953, 12002, 12187, 12434, 12746, 10051, 11661, 12247, 12932 RCA Roku TV: 44211 Realistic: 0178, 10178 Recco: 3847, 0898, 3183 Roku: 14398, 14740, 14487, 11756 Runco: 0017, 10017 Sampo: 11755 Samsung: 12051, 11632, 15386, 15371, 21818, 97817, 77114, 79113, 16616, 36218, 66611, 2051, 3993, 0178, 10702, 10178, 11060 Sankey: 2964 Sansai: 4030 Sansui: 3540, 0463, 1892, 1670, 3564, 4053, 0171, 3559, 10171, 10463, 11409, 11892 Sanyo: 11142, 14168, 14740, 12049, 13488, 11480, 10054, 11564, 11756, 33711, 03818, 10811, 98718, 77715, 88513, 99014, 1142, 1362, 3697, 3861, 1480 Sceptre: 3899, 2528, 2337, 11360, 11599, 12337, 12506 Scotch: 0178, 10178 Scott: 0178, 10178, 11711 Sears: 0156, 0171, 0178, 10047, 10054, 10156, 10178, 10171 Seiki: 3953, 2964, 3559, 3382, 3560, 0178 Semp Toshiba: 1743, 3793, 0156 Sens: 1749 Sense: 11865 Serie Dorada: 3814, 4221 Sharp: 12360, 14618, 14740, 11659, 13519, 13394, 15156, 12402, 14507, 15176, 11756, 14398, 35611, 31713, 91517, 02118, 13019, 37311, 50912, 2360, 3720, 1457, 4398, 10093, 10818 Sharp Roku TV: 55712, 13019 Sheng Chia: 10093 Sherwood: 11399 Sigmac: 3477, 3423 Silo: 3899, 3477, 4182 Sony: 10810, 12778, 14448, 14189, 31912, 89616, 41112, 0810, 10000, 11300 Soundesign: 0178, 10178 Sova: 11952 Soyo: 11520, 11826 Spectroniq: 1523, 1687, 11498 Speler: 4105, 4041 Squareview: 0171, 10171 STI: 3793 SunBriteTV: 2337, 1610, 2528, 11610, 12337 Superscan: 1963, 0171, 10093, 10864, 11944 Supersonic: 2104, 12104, 25811, 41811, 01117, 88715, 44711, 46911 Supreme: 10000 Suzuki: 4434 SVA: 1963, 10748, 10865, 11963 Sylvania: 1864, 1886, 0171, 1963, 1394, 11864, 10054, 11394, 10171, 11271, 11314, 11886, 11944, 11963 Symphonic: 0171, 1963, 1394, 11394, 10171, 11944 Syntax: 1610, 11610, 11144, 11240, 11331 SZK: 4434 Taki: 1540 Tandy: 10093 Tatung: 11756 TCL: 14398, 12434, 13183, 11756, 80313, 36711, 57513, 15919, 68014, 37511, 61513, 44411, 44211, 80312, 2434, 4398, 3183, 2429, 3426, 3847, 2414, 0898, 4178, 26245, 78913, 84416, 33012, 95017, 57011, 6918, 36711, 61514 TCL Roku: 44211 Technics: 0017, 10250, 10051 Techview: 10847 Techwood: 10051 Teknika: 10054, 10150 Telefunken: 2414, 4025, 4302, 10702 TMK: 0178, 10178 TNCi: 0017, 10017 Tonomac: 4221, 4444 Tosaki: 1540, 2357 Toshiba: 11524, 11656, 12724, 15213, 14885, 10156, 67611, 36911, 48512, 36411, 65014, 70017, 70416, 08318, 72014, 90616, 78614, 24919, 57812, 1524, 1656, 0156, 3134, 1743, 11156, 11256, 12006, 11265, 10845, 11704, 11945, 11356 Trutech: 0171, 11723 TVS: 0463, 10463 UpStar: 4182, 4405 Venturer: 11865 Victor: 10053 Vidikron: 10054 Vidtech: 0178, 10178 Viewsonic: 2014, 2745, 2087, 1627, 2049, 2277, 1564, 1365, 12049, 10864, 11564, 10885, 11330, 11365, 11578, 11627, 11742, 12014, 12087, 11755, 10857 Viore: 2352, 3382, 3118, 2104, 3094, 11684, 12104, 12352, 13118 Vizio: 11758, 13758, 14905, 14723, 12707, 12757, 12512, 11756, 35011, 40412, 80016, 20111, 1758, 3758, 2707, 2757, 10864, 10885 Wards: 0178, 0017, 0156, 10156, 11156, 10178, 10047, 10017, 10051, 11347, 10054 Waycon: 0156, 10156 Westinghouse: 1712, 3559, 3382, 2293, 3094, 3470, 2397, 0463, 11712, 10451, 10885, 10889, 11282, 11300, 11577 White Westinghouse: 0623, 0463, 10463, 11661 Wyse: 1365, 11365 Xoceco: 1749 Zenith: 0017, 0178, 0623, 2731, 1365, 2358, 0463, 10000, 11423, 12358, 12731, 10178, 10047,10017, 10463, 11265, 11145, 11661, 11365, 10145 TV BrandCode TypeCodesLG TV4-Digit Code2731, 2358, 3397, 0178, 0017, 1423, 1447, 2424, 1178, 1265, 0856, 19345-Digit Code11423, 10017, 10178, 10856, 11447, 12358, 12424, 12731, 11265, 11136, 11565, 21442, 25641, 31462, 31311, 52412, 63913, 38312, 47312, 58813, 11840, 11860, 14397, 14398, 11756Samsung TV4-Digit Code2051, 3993, 0178, 0702, 0650, 0030, 0766, 08145-Digit Code10702, 10178, 11060, 12051, 11251, 11565, 14241, 14425, 14545, 24366, 21818, 97817, 77114, 79113, 16616, 36218, 66611, 43311, 94818, 38811, 11632, 15386, 15371Hisense TV4-Digit Code3519, 2183, 4398, 3382, 4029, 1314, 1660, 2098, 23555-Digit Code13519, 14740, 14618, 12183, 15156, 15176, 15185, 14656, 11660, 11314, 11756, 13382, 14487, 35611, 44211, 67614, 78115, 59413, 10748, 12098, 12355, 12419, 14355, 24525, 25146, 39812, 61514, 31612, 42113, 39011Hisense Roku TV35611, 44211, 55712, 67614, 78115, 59413, 61514, 72015Insignia TV4-Digit Code2049, 1564, 1326, 1892, 0171, 0463, 1963, 2184, 1423, 0171, 1517, 1660, 1785, 2417, 27515-Digit Code12049, 14487, 11780, 13227, 11564, 11326, 12184, 15213, 11892, 12002, 11423, 10171, 10463, 11385, 11660, 12751, 11756, 28911, 12219, 49412, 28511, 06919, 07216, 69212, 89713, 70017, 39512, 45013, 69613, 82615, 61312, 11204, 11517, 11810, 11963, 12049, 12417, 11554, 13162, 21442, 22116, 22235, 22641, 23244, 23543, 24142, 24245, 24364, 25151, 26216, 33646, 68515, 22011, 57513, 47913, 36412, 40211, 64713, 56111, 79016, 21711, 74115, 41011, 73114Sony TV4-Digit Code0810, 1300, 1317, 16855-Digit Code31912, 89616, 41112, 10000, 10810, 12778, 14448, 14189, 11300, 14541, 21115, 22556, 26411, 44613, 33211, 44411, 44211TCL TV4-Digit Code2434, 4398, 3183, 2429, 3426, 3847, 2414, 0898, 4178, 69185-Digit Code14398, 12434, 13183, 11756, 80313, 36711, 57513, 15919, 68014, 37511, 61513, 44411, 44211, 80312, 26245, 78913, 84416, 33012, 95017, 57011, 36711, 61514TCL Roku TV44211, 61514Vizio TV4-Digit Code1758, 3758, 2707, 2757, 0864, 1756, 08855-Digit Code11758, 13758, 14905, 14723, 12707, 12757, 35011, 40412, 80016, 20111, 12512, 11756, 10864, 10885, 15111, 15144, 23155, 23161, 26455, 31544, 36333, 13415, 22111, 28911, 51914, 34112, 14905, 14723 American High 0035 Canon 0035 Carver 0081 Crosley 0081 Curtis Mathes 0035, 0060, 0162 Daewoo 0045 Emerex 0032 Fuji 0035 GE 0060, 0035, 0202 Harman/Kardon 0081 Instant Replay 0035 JC Penney 0035 Kodak 0035 Magnavox 0035, 0081 Marantz 0081, 0035 Matsushita 0035, 0162 MEI 0035 Memorex 0035, 0162 Motorola 0035 NAP 0035 Olympus 0035 Optimus 0162 Panasonic 0035, 0162 Penney 0035 Philco 0035 Philips 0081, 0035 Polk Audio 0081 Proscan 0060, 0202 Quasar 0035, 0162 RCA 0060, 0202, 0035 RCN 0060 Realistic 0035 Samsung 0045 Scott 0045 Sears 0035 Semp Toshiba 0045 Toshiba 0045 Signature 0035 Signature 2000, 0035 Sony 0032, 0035 Sylvania 0035, 0081 Technics 0035, 0162, 0060, 0202 Teknika 0035 Toshiba 0045 Vector 0045 Video Concepts 0045 Wards 0035, 0045, 0060, 0081 XR-1000 0035 Arion 1279, 4348 Arris 0869 AZ America 3599 Bell 0775 Bell ExpressVu 0775 Bell Satellite TV 0775 Century 0856 Claro 4546, 3790 Coship 4546, 3790 DirecTV 1377, 1442 Dish Mexico 0775 Dish Network 0775 Dishpro 0775 Echostar 0775, 2262, 2527 Embratel 4546 Frontier Communications 0775 General Instrument .0869 GOI 0775 Gradiente 0887, 0856 GVT 3789 HTS 0775 Huawei 4546 Hughes Network Systems 1442, 1377 Humax 1377 Intv 4348 Jerrold 0869 JVC 0775 LG 1377 Motorola 0869, 0856, 3469 Movistar 2527, 2262 Nagra 2262 Netgem 3637 Netsat 0887 Next Level 0869 Oi TV 4460 Pace 0887, 3469, 1377, 2895, 3111, 3790, 4546 Philips 1442, 2619, 0856, 0887, 3469 RadioShack 0869 RCA 1442 Sagem 1692 Sagemcom 3789 Samsung 1442, 1377 Shaw Direct 0869, 0775 Sky Brasil 1377, 0887, 0856, 2619, 3111 Sky Mexico 3469, 2619, 0856, 0887, 1377 Star 0887 Star Choice 0869 Supernova 0887 TDS Telecom 0775 Technicolor 3790, 3469 Tele Red 1279 Telefonica 1692, 2262, 2527 Televisa 0887 TELUS 0775 Thomson 3469, 1377, 2619 TiVo 1377, 1442 TVA Digital 2895, 1692, 2262 UNE 1692 Via Embratel 4546 Vivo 2262, 2895, 1692, 2527 Windstream 0775 Zenith 0856, 3469 Access Communications 1376, 2187 Adams Cable TV 1376, 4079 ADB 2254, 1481, 1998, 2302, 3028 Allegiance Communications 1376 Amino 1615, 1481, 2482, 1998, 2302, 3028 Arion 3336 Armstrong 1376, 3560 Arris 1376, 1998, 2187, 1982 Arvig Communication Systems 1376, 1982, 1998, 3028 AT&T 0858, 1877, 2187 AT&T U-verse 0858, 1877, 2187 Atlantic Broadband 1877, 3560, 1376, 4079 ATMC 1376, 1982, 3028, 1998 Bell 1998, 1877 Bell Aliant 1998 Bell Fibe TV 1998 Blue Ridge Communications 1877, 3560 Bright House 1877, 1376, 3294 Broadstripe 1376 Buckeye Cable System 1376, 2187, 1877 Cable America 1376, 1877 Cable Axion Digitel 1376 Cable One 1376, 3560, 1877 Cablecom Mexico 1376 Cablem·s 3119, 1376, 1877 Cablevision 1376, 1877, 3336, 4375 Cablevision du Nord 1376 Cablevision Victoria 1376, 4375 Cass Cable 1376 CCAP 1877 CenturyLink 1998 Channel Master 3118 Charter 1376, 1877, 2187, 3560 Choice Cable TV 1376, 1877, 1982 Cincinnati Bell 1877, 1376 Cisco 1877, 3028, 0858, 1982, 1883, 2506, 1376, 4374, 4514, 2826, 3294, 4450 Claro 1376, 1998, 3028 Cogeco 1376, 1982, 3560 Comcast 1982, 1376, 1877, 3560, 2187 Comporium 1877, 3560, 2187 Consolidated Communications 1877, 1376, 1998, 2302, 3048 Convenient 3527 Cox 1877, 1376, 3774, 4315 Digeo 2187 Eagle Communications 1376, 2187 EastLink 1376, 2187 Echostar 3452, 3454 Entone 3048, 2302, 1615 Evolution 2479, 4079, 2746, 4315 Fidelity Communications 1376 Frontier Communications 1376 General Communications 3560, 1376, 1877 Google 3666 Grande Communications 1877, 3560, 1376 Great Plains Communications 1376 Hawaiian Telcom 3028 Huawei 4589, 1982, 4883 Humax 3560 Inter Mountain Cable 1877, 2479, 4079, 2826, 3294 Izzi Telecom 1376 Kathrein 3288 LG 4343 Liberty Cablevision 1376 Lumos Networks 1998, 3028 Massillon Cable 1376, 2187 Maxcom 1998 Mediacom 1376, 3560, 1982, 1877 Mediastream 1376 Megacable 1376, 4374, 4450, 4514, 2506, 4375, 4883 Megaseñal 3527 MetroCast Cablevision 1376, 1982, 1877 Mi-Connection 1877 Midcontinent Communications 1376, 1982, 3560, 2826, 4079 Mid-Hudson Cable 1376 Motorola 1376, 1998, 0858, 1982, 4375 Movistar 3288 Moxi 2187 MTS 1998 NET 1883 Netgem 4634 NewWave Communications 1376, 2187 Northland Communications 1376 NU Telecom 1998, 3028 Oi TV 3454, 3452 Optimum 1877 Pace 1376, 1982, 1877, 3454, 0858, 1883, 3560, 1998 Panasonic 1982 Philips 1376, 3560 Pioneer 1877 RCN 1376, 3560, 1877 Reach Broadband 1376, 1877, 1982 Rogers 1877, 1376, 2826, 3294 Sagem 3288 Sagemcom 3288 Samsung 1877, 3928, 1982 SaskTel 1998, 1737 Schurz Communications 1376, 1877, 1982 Scientific Atlanta 1877, 0858, 3028, 1982, 1376, 2826 Service Electric 1376, 1982, 1877, 2187 Shaw 1376, 1877, 2187, 1982 Shentel 1376, 1877, 1982, 2187 Sogetel 1998, 2482 Source Cable 1376 Suddenlink 1877, 1376, 3560, 1982 Supercanal 1376 Tbaytel 1998 TDS 1376, 1877, 1982 Technicolor 1982, 3288, 3454 TeleCable 1376 Telecentro 1376 Telefonica 3028, 3288 Telmex 1376 TELUS 3028 Thomson 1982 Time Warner 1877, 1376, 2187, 3294 TiVo 3560 Totalplay 4634, 4589, 4591 TV Cable 1376 TVS Cable 1376, 1877, 1982 UNE 2506 U-verse 0858, 1877, 2187 Verizon 1376 Vidéotron 1877, 1376 Vivo 3288 VTR 1376 Wave Broadband 1376, 2479, 3560, 4079, 2187 Wavevision 1376, 1877, 1982 WEHCO Video 1376 Westman Communications 1376, 2187 WideOpenWest 1376, 1877, 2187 Windjammer Cable 1376, 1877 WNC 3118 WOW! 1877, 1376, 2187, 2479, 2826, 3294 Xfinity 1982, 1376, 1877, 3560, 2187 Zito Media 1376, 1877, 1982 Z-Trak 1376 Accurian 0675 California Audio Labs 0490 Curtis Mathes 2331 Denon 1634, 2258, 0490 Disney 0675 Durabrand 3464 Dynex 2596 Emerson 0675, 2213 Funai 0675 GE 0522 General Electric 0522 GFM 0675 Go Video 1075, 0741 GoldStar 0741 Grundig 0539 Hitachi 0573, 0675 HitPlus 2583 Insignia 2596, 2095, 2428, 0675, 0741 Integra 2147, 1634 JVC 0741 Kenwood 0490 Lenoxx 2213 LG 0741 Magnavox 0675, 0503, 0539 Marantz 0539 Memorex 2213, 2331 Microsoft 2083, 2627, 0522 NAD 0741 New Acoustic Dimension 0741 Olevia 2331 Onkyo 2147, 0503 Panasonic 1641, 3641, 0490, 0503 Philco 0675 Philips 2056, 2434, 0539, 0503, 2084, 0675 Pioneer 2442 Polk Audio 0539 Presidian 0675 Proscan 0522 RCA 0522, 2587, 2213, 2532, 3464 Samsung 0199, 0573, 1075, 2069, 2489, 0490 Semp Toshiba 0503 Sharp 2250, 0675 Shinsonic 0533 Sony 1516, 1633, 0533, 0864, 1070 SV2000 0675 Sylvania 0675 Symphonic 0675 TCL 2587 Technics 0490 Toshiba 0503, 2277, 3157, 2705 TruTech 0675 Urban Concepts 0503 VIZIO 2563 Vtrek 2583, 2587 Xbox 2083, 2627, 0522 Yamaha 2298, 0539, 0490 Zenith 0741, 0503 Access HD 2185 Alpha Digital 2185 AMTC 2185 Centronics 2360 Channel Master 2360 Digiwave 2360 Dish Network 2470 Echostar 2470 Firebird Systems 2360 GE 2360 General Electric 2360 Goodmind 2360 iNet Access 2185 Insignia 1415 LG 1415 RTC 2360 Tivax 2185 Zenith 1415 Universal remotes come with support for more than one device. So you might also be looking to program the remote for other electronic devices like DVDs, Consoles, and more. Also if you want a printable code list, then you can download a printable file from the link below. Download Printable RCA Remote Codes Now that you have access to RCA remote codes, its time for the program guide. You can follow the without codes method if you didn't find your device on the list. No matter what RCA Universal Remote Control you have, the steps to program the remote to your TV will be the same. The same can be said regardless of the TV brand that you plan to use the RCA Universal Remote with. Before moving to the steps, note down the codes you will need for your particular TV brand. We have listed all the control codes below. Or you can check the manual received with your Remote. Step 1: Insert batteries in your RCA remote. Also, power up your TV. Step 2: Press and hold the TV key on your remote while pointing the remote towards the TV. Or press and hold another device key if you want to connect another device like Cable, DVD, etc. Step 3: Release the device key once the power key on the remote light up. Step 4: While the Power button is lit, enter the pairing code for your device from the list. Step 5: When you enter the correct code, Power key light will turn off. Once programmed, test the remote functions with your device. If the power button led blinks twice, this means you have entered the incorrect code. So try the second code and other codes as well until the power button turns off. Step 1: Power On your TV. Point the Remote towards TV/device for the whole process. Step 2: Press and hold the TV key. Hold the specific device key if you are programming it for another device (like DVD, VCR). Step 3: While holding TV key, also press and hold the Power key. The power key or LED indicator will turn on. Now you can release both keys. Step 4: While pointing the remote to TV, Press the Play key and wait for 5 seconds. If TV/device turns off move to next step. If not, press the Play key again and wait 5 seconds. Repeat the process until your device turns off. Step 5: Once your TV turns off, press the Reverse key and wait for at least 2 seconds. If your TV/device turns on, move to next step. If not, press the Reverse key and repeat the process. Step 6: When your TV/device turns back On, immediately press the Stop key to save the code. Now your RCA remote is programmed and you can test the remote. Check if the basic functions such as power volume, channel, menu, and source buttons are working perfectly or not. Step 1: Make sure your device is turned on and you are aiming the remote towards the device. Press and hold the Code Search key on your Remote until the indicator light turns on. Step 2: Now press and release the device key, e.g. TV key if you are programming for your TV. Step 3: Enter the code manually. You can check the codes from the list above or from the manual you have received with your Remote. Step 4: After entering the correct code, the indicator light will turn off. Now you can test your Remote with your device. If the indicator light flashes twice after entering a code, this means the code is incorrect. Then you can try other codes. Step 1: Turn on your TV or other device that you want to program with RCA Remote. Point the Remote towards the device for the process. Step 2: Press and hold the Code Search Key until the LED turns on. Step 3: Press and release the Device key, for example TV key if you are programming for TV. The indicator light will blink once and stay lit. Step 4: Now press and release the Power key until your device turn off. You might need to press the key up to 200 times. Step 5: When your device turn off, immediately press the Enter key (within 4 seconds) to save the code and the indicator LED will turn off. There are various RCA universal remote models to choose from. Here are currently available RCA Universal Remote Controls. 2-Device and 3-Device RCA Remote Controllers RCR313BE RCR3273E RCR503BE RCRH02BE RCRN03BE 4-Device and 5-Device RCA Remote Controllers RCR414BHE RCR504BE RCRBB04GBE RCRBB05BHE RCRBB05BHZ RCRN04GBE RCRPST04BE RCRPST05BE RCRTBL04BE 6-Device and 8-Devices RCA Remote Controllers RCR6473E RCRN06GBE RCRPST06GBE RCRTBL06BE This concludes the guide on how you can pair and program an RCA universal Remote with any TV brand that you own. With such remote codes, you can make use of a universal remote easily. So, the next time you lose a TV remote, always be assured that the RCA Remote is there to save you. If you have questions or queries, feel free to leave them in the comments section below. Related Articles: Remote Controls > RCA TV codes (5 digits v.2) Five digit TV codes for newer RCR003RWDE, RCR3273E, RCR413BHE, RCR414BHE, RCR504BE, RCR6473E, RCRBB04GBE, RCRH02BE, RCRN06GBE, RCRPST04BE, RCRPST05SE, RCRPST06GBE1, RCU300TE and other similar RCA universal remote controls with code revision R271U1 and R271U2. You can find out your remote's code revision number from a sticker inside the battery compartment. See also: Programming instructions (for rev. R271U1 & R271U2). TV BrandRCA 5 digit code (v.2) Abex69913 64911 Accurian91814 Acer16317 59114 42919 ADC33719 65312 Advent91019 71014 99715 50411 Affinity07819 Aftron01219 Aiko63511 Aiwa40411 66111 Akai97817 09619 90117 43514 94219 Alleron54711 Amtron79513 AMW75214 64013 Anam National78613 57611 79513 58211 49219 AOC31811 19819 40413 44211 53313 31612 33411 52713 33412 AOC (Roku TV)44211 Apex75217 54214 42113 76314 47111 60113 06016 84715 39019 Apex Digital39019 Ario68515 Atvio21711 63315 44211 64615 38111 Atvio (Roku TV)44211 Atyme52013 Audiovox79513 75512 86413 Auria31612 33412 Aurora46014 Auvio46513 57014 Aventura88518 Avera68515 Avol87217 89115 Axess41811 Axion84315 Bang & Olufsen24011 Bell & Howell26618 65312 98215 BenQ87813 95719 31919 80014 Blue Sky98314 95017 Boe89013 19819 Bolva72015 Brockwood43411 Broksonic81017 65813 57812 75614 55711 54411 CCE95017 Celera86718 42113 Centrios82614 Cetomer83314 40412 Cetronic78613 Changhong01618 72117 Charter Communications80415 Chimei24912 Cielo30812 Cineral63511 95017 Citizen58412 60112 93115 78613 79513 63511 Classic46311 04616 78613 CLP43311 CLP Classic43411 79914 Coby13011 77617 96315 52411 52211 61611 77912 Colortyme33719 Comwave32611 Contec54312 56511 78613 79513 Contex20011 Cornea66712 Craig19311 24912 23211 78613 79513 Crosley19711 56011 79914 Crown78613 79513 Crystal72117 CTX55411 Curtis11711 47913 68515 79016 80517 64615 20011 Curtis International07819 47913 68515 79016 80517 91118 Curtis Mathes90614 17411 58012 58412 26618 98215 66611 Cybervision95017 Daewoo74412 42211 84014 78613 68912 63511 33411 85817 90214 Daytron43411 Dell40211 61211 65411 92815 95017 Devant94818 27911 05319 Diamond Vision59612 86115 54911 57111 Digihome71415 37811 Digimate63111 Digistar42214 71014 65411 78112 Digital83618 Digitor33113 Disney81017 Distar84218 DSE22612 Dukane37219 67412 Durabrand39213 88518 86718 81017 55514 93115 Dynasty78613 Dynex12219 49412 39213 45013 82717 49813 61215 27311 28511 27711 06919 28911 39512 89713 79914 88518 Electro54312 56111 Electron80517 Elekta83618 Elektra52814 65312 Element01815 70017 44211 81918 45112 72015 34211 79517 24912 34611 Element (Roku TV)44211 Emerson29311 36412 48111 82615 88518 46911 71714 75614 40411 26618 54711 79513 85913 99714 Envision40413 31612 33412 EQD31612 33412 ESA88518 25011 93115 Favi11711 Fire TV70017 65014 42113 01815 Fisher26618 72112 66011 Fluid70013 Fujicom76615 Fujitsu54711 74012 Funai88518 29311 25011 48111 40411 54711 Furrion47414 27911 Futuretec78613 79513 Gateway20111 59912 GE (General Electric)50115 14951 55514 42113 87215 73814 90015 00615 General Instrument39019 GFM88518 29311 03419 25011 Gibralter74916 53511 53911 Globalstar49011 Goldi89013 GoldStar55514 40411 33411 GPX24611 23611 46911 Gradiente43411 81214 92114 09215 65311 Grundig37911 Guestvision53311 Gvision88113 Haier56013 12511 60914 44211 11711 55514 43912 54513 77612 Haier (Roku TV)44211 Hallmark55514 Hannspree15811 26812 Hauppauge65911 Havermy22511 Hello Kitty78212 Hidear68211 Hisense35611 44211 67614 55712 78115 65014 42113 59413 Hisense (Roku TV)44211 55712 Hitachi13611 44913 44211 49012 37811 61513 Hitachi (Roku TV)44211 HKC47414 Hkpro38811 HP (Hewlett Packard)38013 83013 Hyundai66213 63811 01115 Ikon34112 iLo28118 93115 89514 56811 94215 05816 03715 88518 Infinity51011 56011 Infocus35912 38618 Initial62213 89514 74213 Insignia28911 12219 49412 28511 44211 06919 07216 69212 89713 70017 39512 45013 69613 82615 61312 Insignia (Roku TV)12219 44211 Intec38011 Inteq74916 53511 53911 iSymphony11711 JBL56011 JC Penney87215 58412 60112 55211 98215 90015 49219 33411 Jensen69212 Jocel67211 JVC11719 99717 00218 44211 48812 48611 77213 87314 JVC (Roku TV)44211 Kalley01115 Kawasaki47011 Kawasho56111 KC20611 KDS40114 58414 KEC78613 KLH42113 Kloss Novabeam68413 Knoll Systems (Zenith)74916 Kogi88113 Konka45013 66213 32319 22218 96514 Kreisen97619 KTC27019 KTV15311 54312 88114 78613 79513 Kurazai65312 Kworld72813 Lasonic86115 54911 Leader96319 Leege10011 Legend68515 71014 Lenovo90919 Lenson66116 LeTV56614 67115 LG31311 52412 63913 Liquidvideo84315 17517 Lodgenet65312 98215 80714 08415 Loewe56011 Logik98215 Luce70514 LXI55514 58012 53112 40411 26618 60112 98215 56011 MAG40114 58414 Magnasonic54711 Magnavox95017 42812 88518 25011 44211 42513 48111 82615 51011 63011 Magnavox (Roku TV)44211 Majestic98215 Marantz33412 53811 56011 Master-G01115 Matsushita39011 Maxent27117 59912 Medion95515 28118 69112 Megatron55514 37219 MEI54312 Melody36711 Memorex20212 55514 53014 12219 74414 85915 65813 57812 26618 98215 54711 MGA55514 54711 75413 56511 67012 33411 Mi21012 Midland74916 87215 58012 53112 98215 53511 53911 64511 Minoka36913 Mintek60916 Minutz90015 Misakai93115 Mitsubishi21711 33411 70215 36311 78112 97415 54711 Mitsui21711 70215 36311 78112 19311 17711 29312 30813 41314 52215 18311 18711 89713 Monivision48011 Montgomery Ward65312 98215 Moteva26618 92114 Motorola63712 MTC54312 58412 60112 33411 Myron & Davis91615 NAD55514 60112 64911 Naxa82318 11711 25811 29419 41011 NEC29811 31912 47811 53811 33411 Net TV46511 59912 Nexus36412 82717 Nexxtech62313 62912 Nikai84218 Nikkei78613 Nikko55514 63511 Niko47719 Nobel80313 Norcent40413 68912 NTC63511 NuVision02315 Oboni17711 94219 85818 Olevia80118 17211 85114 Oncommand53311 65711 Onn57513 44211 43612 32011 00717 Onn (Roku TV)44211 Onwa78613 79513 Optimus64812 39011 Optoma81614 Optonica47811 55411 Orion21311 81017 53511 53911 Palsonic73717 Panasonic39011 39811 51913 60513 79515 Panda18911 18411 PARK25811 Peerless18918 Penney55514 Philco25011 41212 63214 76813 92815 01115 33411 52814 Philips62414 17419 33412 06918 73915 84416 95017 44211 21319 43911 48111 82615 88518 Philips (Roku TV)44211 Philips-Magnavox56011 69411 73915 86815 51011 Pioneer69913 53714 73513 53811 Piva86914 Pixel99119 Planar40413 75812 Polaroid89013 33211 68515 24912 40114 58414 42113 20011 65014 94016 43319 07015 67211 16611 Portland63511 33411 Precision64713 Prima27311 66213 71014 Princeton Graphics59611 55411 Prism01117 Promac26711 Proscan47414 11711 34211 07819 93218 20011 35611 07017 01815 79712 69416 Proton55514 Protron32818 63111 Proview24912 Pulsar74916 53511 53911 Pyle68016 Pyle Home68016 QFX41811 Quasar87215 64812 56011 51913 39011 Radio Shack55514 47811 40411 26618 98215 54311 56511 79513 00615 RCA66114 44712 54113 11711 44211 58915 69416 36412 04719 26411 22511 33012 44613 55213 65714 43912 61513 67013 90214 79712 32111 RCA (Roku TV)44211 Realistic55514 57512 47811 40411 26618 98215 78613 79513 79515 Revolution HD93819 Riviera90614 50613 Roku TV44211 55712 12219 13019 Rowa53815 Runco74916 53511 53911 53811 Séura13019 05517 Sampo59912 Samsung21818 97817 77114 79113 16616 36218 66611 Samtron58412 Sansui39213 20011 88518 57812 54411 Sanyo33711 03818 44211 10811 98718 77715 88513 99014 Sanyo (Roku TV)44211 Sceptre37313 19711 65815 20611 30211 83515 05115 Scotch55514 Scott55514 54711 78613 79513 94215 Sears55514 57812 58412 48111 82615 59211 60112 93115 98215 54711 56011 68612 72112 Seiki64814 01815 79517 55514 96416 11218 22719 Selectron74313 85814 78112 Semp70712 Sharp35611 31713 55712 91517 02118 13019 37311 50912 Sharp (Roku TV)55712 13019 Sheng-Chia22511 Sigmac02019 Signature98215 Signet96715 83414 50911 Silo Digital20611 Simply76716 Siragon26211 Skyvue37712 Skyworth59315 14319 62415 56112 67211 Soaiy89117 Sole93819 Sonic54312 Sony31912 89616 41112 Soulaca16118 Soundesign55514 54711 78613 79513 Sova81213 85613 Soyo69613 Spectra54911 Spectravision58611 Spectroniq48814 Speler41313 Squareview88518 93115 Star Sat50913 Starlite79513 Sumec10818 SunBriteTV19711 65815 92918 80118 20611 Super General84218 Superscan48111 82615 Supersonic25811 41811 01117 88715 44711 46911 Supra72117 43411 78913 SVA25011 Sylvania29311 25011 48111 40411 88518 81017 75315 63614 74115 82615 56011 Symphonic88518 48111 82615 40411 93115 79513 Syntax64716 Tatung20111 28118 31919 TCL80313 36711 44211 57513 15919 44411 68014 01815 37511 61513 TCL (Roku TV)44211 Technicolor65714 Technics87215 39011 Techwood87215 73513 Teknika68413 58412 60112 98215 54711 78613 63511 33411 79515 Telerent65312 98215 Tera43411 Tevion28118 Thomson80313 Thtf21412 32913 TMK55514 TNCi74916 Toshiba67611 36911 48512 36411 65014 70017 70416 08318 72014 90616 78614 24919 57812 TruTech88518 24912 76312 TVA38511 TVS81017 Universal42611 90015 Upstar27411 51914 Venturer51611 65911 Vestel71415 Victor77213 64811 Videocon97914 Vidtech55514 33411 Viewsonic47312 92419 12911 23512 34413 45914 56415 12311 23812 10111 10511 59912 31612 67412 33412 Vimax54015 Viore11711 25811 47913 94915 Vision Quest68411 24912 Vivitek80213 44384 Vizio35011 40412 80016 20111 Wards74916 55514 81015 47811 71013 98215 54711 90015 56011 33411 Waycon70416 Wbox12618 23219 45211 Westinghouse58813 31912 44211 69314 11711 68515 48213 30611 43711 70713 01815 Westinghouse (Roku TV)44211 White-Westinghouse81017 53212 40411 90214 Windsor37811 Wyse34413 Xiaomi21012 Xoceco14011 14811 16611 Yamaha33411 79515 Zenith64512 53014 43311 40411 51712 95216 51011 15117 54411 57011 64311 63511 85913 66611 Zutest49611 Remote Controls > RCA TV codes (5 digits v.2) Five digit TV codes for newer RCR003RWDE, RCR3273E, RCR413BHE, RCR414BHE, RCR504BE, RCR6473E, RCRBB04GBE, RCRH02BE, RCRN06GBE, RCRPST04BE, RCRPST05SE, RCRPST06GBE1, RCU300TE and other similar RCA universal remote controls with code revision R271U1 and R271U2. You can find out your remote's code revision number from a sticker inside the battery compartment. See also: Programming instructions (for rev. R271U1 & R271U2). TV BrandRCA 5 digit code (v.2) Abex69913 64911 Accurian91814 Acer16317 59114 42919 ADC33719 65312 Advent91019 71014 99715 50411 Affinity07819 Aftron01219 Aiko63511 Aiwa40411 66111 Akai97817 09619 90117 43514 94219 Alleron54711 Amtron79513 AMW75214 64013 Anam National78613 57611 79513 58211 49219 AOC31811 19819 40413 44211 53313 31612 33411 52713 33412 AOC (Roku TV)44211 Apex75217 54214 42113 76314 47111 60113 06016 84715 39019 Apex Digital39019 Ario68515 Atvio21711 63315 44211 64615 38111 Atvio (Roku TV)44211 Atyme52013 Audiovox79513 75512 86413 Auria31612 33412 Aurora46014 Auvio46513 57014 Aventura88518 Avera68515 Avol87217 89115 Axess41811 Axion84315 Bang & Olufsen24011 Bell & Howell26618 65312 98215 BenQ87813 95719 31919 80014 Blue Sky98314 95017 Boe89013 19819 Bolva72015 Brockwood43411 Broksonic81017 65813 57812 75614 55711 54411 CCE95017 Celera86718 42113 Centrios82614 Cetomer83314 40412 Cetronic78613 Changhong01618 72117 Charter Communications80415 Chimei24912 Cielo30812 Cineral63511 95017 Citizen58412 60112 93115 78613 79513 63511 Classic46311 04616 78613 CLP43311 CLP Classic43411 79914 Coby13011 77617 96315 52411 52211 61611 77912 Colortyme33719 Comwave32611 Contec54312 56511 78613 79513 Contex20011 Cornea66712 Craig19311 24912 23211 78613 79513 Crosley19711 56011 79914 Crown78613 79513 Crystal72117 CTX55411 Curtis11711 47913 68515 79016 80517 64615 20011 Curtis International07819 47913 68515 79016 80517 91118 Curtis Mathes90614 17411 58012 58412 26618 98215 66611 Cybervision95017 Daewoo74412 42211 84014 78613 68912 63511 33411 85817 90214 Daytron43411 Dell40211 61211 65411 92815 95017 Devant94818 27911 05319 Diamond Vision59612 86115 54911 57111 Digihome71415 37811 Digimate63111 Digistar42214 71014 65411 78112 Digital83618 Digitor33113 Disney81017 Distar84218 DSE22612 Dukane37219 67412 Durabrand39213 88518 86718 81017 55514 93115 Dynasty78613 Dynex12219 49412 39213 45013 82717 49813 61215 27311 28511 27711 06919 28911 39512 89713 79914 88518 Electro54312 56111 Electron80517 Elekta83618 Elektra52814 65312 Element01815 70017 44211 81918 45112 72015 34211 79517 24912 34611 Element (Roku TV)44211 Emerson29311 36412 48111 82615 88518 46911 71714 75614 40411 26618 54711 79513 85913 99714 Envision40413 31612 33412 EQD31612 33412 ESA88518 25011 93115 Favi11711 Fire TV70017 65014 42113 01815 Fisher26618 72112 66011 Fluid70013 Fujicom76615 Fujitsu54711 74012 Funai88518 29311 25011 48111 40411 54711 Furrion47414 27911 Futuretec78613 79513 Gateway20111 59912 GE (General Electric)50115 14951 55514 42113 87215 73814 90015 00615 General Instrument39019 GFM88518 29311 03419 25011 Gibralter74916 53511 53911 Globalstar49011 Goldi89013 GoldStar55514 40411 33411 GPX24611 23611 46911 Gradiente43411 81214 92114 09215 65311 Grundig37911 Guestvision53311 Gvision88113 Haier56013 12511 60914 44211 11711 55514 43912 54513 77612 Haier (Roku TV)44211 Hallmark55514 Hannspree15811 26812 Hauppauge65911 Havermy22511 Hello Kitty78212 Hidear68211 Hisense35611 44211 67614 55712 78115 65014 42113 59413 Hisense (Roku TV)44211 55712 Hitachi13611 44913 44211 49012 37811 61513 Hitachi (Roku TV)44211 HKC47414 Hkpro38811 HP (Hewlett Packard)38013 83013 Hyundai66213 63811 01115 Ikon34112 iLo28118 93115 89514 56811 94215 05816 03715 88518 Infinity51011 56011 Infocus35912 38618 Initial62213 89514 74213 Insignia28911 12219 49412 28511 44211 06919 07216 69212 89713 70017 39512 45013 69613 82615 61312 Insignia (Roku TV)12219 44211 Intec38011 Inteq74916 53511 53911 iSymphony11711 JBL56011 JC Penney87215 58412 60112 55211 98215 90015 49219 33411 Jensen69212 Jocel67211 JVC11719 99717 00218 44211 48812 48611 77213 87314 JVC (Roku TV)44211 Kalley01115 Kawasaki47011 Kawasho56111 KC20611 KDS40114 58414 KEC78613 KLH42113 Kloss Novabeam68413 Knoll Systems (Zenith)74916 Kogi88113 Konka45013 66213 32319 22218 96514 Kreisen97619 KTC27019 KTV15311 54312 88114 78613 79513 Kurazai65312 Kworld72813 Lasonic86115 54911 Leader96319 Leege10011 Legend68515 71014 Lenovo90919 Lenson66116 LeTV56614 67115 LG31311 52412 63913 Liquidvideo84315 17517 Lodgenet65312 98215 80714 08415 Loewe56011 Logik98215 Luce70514 LXI55514 58012 53112 40411 26618 60112 98215 56011 MAG40114 58414 Magnasonic54711 Magnavox95017 42812 88518 25011 44211 42513 48111 82615 51011 63011 Magnavox (Roku TV)44211 Majestic98215 Marantz33412 53811 56011 Master-G01115 Matsushita39011 Maxent27117 59912 Medion95515 28118 69112 Megatron55514 37219 MEI54312 Melody36711 Memorex20212 55514 53014 12219 74414 85915 65813 57812 26618 98215 54711 MGA55514 54711 75413 56511 67012 33411 Mi21012 Midland74916 87215 58012 53112 98215 53511 53911 64511 Minoka36913 Mintek60916 Minutz90015 Misakai93115 Mitsubishi21711 33411 70215 36311 78112 97415 54711 Mitsui21711 70215 36311 78112 19311 17711 29312 30813 41314 52215 18311 18711 89713 Monivision48011 Montgomery Ward65312 98215 Moteva26618 92114 Motorola63712 MTC54312 58412 60112 33411 Myron & Davis91615 NAD55514 60112 64911 Naxa82318 11711 25811 29419 41011 NEC29811 31912 47811 53811 33411 Net TV46511 59912 Nexus36412 82717 Nexxtech62313 62912 Nikai84218 Nikkei78613 Nikko55514 63511 Niko47719 Nobel80313 Norcent40413 68912 NTC63511 NuVision02315 Oboni17711 94219 85818 Olevia80118 17211 85114 Oncommand53311 65711 Onn57513 44211 43612 32011 00717 Onn (Roku TV)44211 Onwa78613 79513 Optimus64812 39011 Optoma81614 Optonica47811 55411 Orion21311 81017 53511 53911 Palsonic73717 Panasonic39011 39811 51913 60513 79515 Panda18911 18411 PARK25811 Peerless18918 Penney55514 Philco25011 41212 63214 76813 92815 01115 33411 52814 Philips62414 17419 33412 06918 73915 84416 95017 44211 21319 43911 48111 82615 88518 Philips (Roku TV)44211 Philips-Magnavox56011 69411 73915 86815 51011 Pioneer69913 53714 73513 53811 Piva86914 Pixel99119 Planar40413 75812 Polaroid89013 33211 68515 24912 40114 58414 42113 20011 65014 94016 43319 07015 67211 16611 Portland63511 33411 Precision64713 Prima27311 66213 71014 Princeton Graphics59611 55411 Prism01117 Promac26711 Proscan47414 11711 34211 07819 93218 20011 35611 07017 01815 79712 69416 Proton55514 Protron32818 63111 Proview24912 Pulsar74916 53511 53911 Pyle68016 Pyle Home68016 QFX41811 Quasar87215 64812 56011 51913 39011 Radio Shack55514 47811 40411 26618 98215 54311 56511 79513 00615 RCA66114 44712 54113 11711 44211 58915 69416 36412 04719 26411 22511 33012 44613 55213 65714 43912 61513 67013 90214 79712 32111 RCA (Roku TV)44211 Realistic55514 57512 47811 40411 26618 98215 78613 79513 79515 Revolution HD93819 Riviera90614 50613 Roku TV44211 55712 12219 13019 Rowa53815 Runco74916 53511 53911 53811 Séura13019 05517 Sampo59912 Samsung21818 97817 77114 79113 16616 36218 66611 Samtron58412 Sansui39213 20011 88518 57812 54411 Sanyo33711 03818 44211 10811 98718 77715 88513 99014 Sanyo (Roku TV)44211 Sceptre37313 19711 65815 20611 30211 83515 05115 Scotch55514 Scott55514 54711 78613 79513 94215 Sears55514 57812 58412 48111 82615 59211 60112 93115 98215 54711 56011 68612 72112 Seiki64814 01815 79517 55514 96416 11218 22719 Selectron74313 85814 78112 Semp70712 Sharp35611 31713 55712 91517 02118 13019 37311 50912 Sharp (Roku TV)55712 13019 Sheng-Chia22511 Sigmac02019 Signature98215 Signet96715 83414 50911 Silo Digital20611 Simply76716 Siragon26211 Skyvue37712 Skyworth59315 14319 62415 56112 67211 Soaiy89117 Sole93819 Sonic54312 Sony31912 89616 41112 Soulaca16118 Soundesign55514 54711 78613 79513 Sova81213 85613 Soyo69613 Spectra54911 Spectravision58611 Spectroniq48814 Speler41313 Squareview88518 93115 Star Sat50913 Starlite79513 Sumec10818 SunBriteTV19711 65815 92918 80118 20611 Super General84218 Superscan48111 82615 Supersonic25811 41811 01117 88715 44711 46911 Supra72117 43411 78913 SVA25011 Sylvania29311 25011 48111 40411 88518 81017 75315 63614 74115 82615 56011 Symphonic88518 48111 82615 40411 93115 79513 Syntax64716 Tatung20111 28118 31919 TCL80313 36711 44211 57513 15919 44411 68014 01815 37511 61513 TCL (Roku TV)44211 Technicolor65714 Technics87215 39011 Techwood87215 73513 Teknika68413 58412 60112 98215 54711 78613 63511 33411 79515 Telerent65312 98215 Tera43411 Tevion28118 Thomson80313 Thtf21412 32913 TMK55514 TNCi74916 Toshiba67611 36911 48512 36411 65014 70017 70416 08318 72014 90616 78614 24919 57812 TruTech88518 24912 76312 TVA38511 TVS81017 Universal42611 90015 Upstar27411 51914 Venturer51611 65911 Vestel71415 Victor77213 64811 Videocon97914 Vidtech55514 33411 Viewsonic47312 92419 12911 23512 34413 45914 56415 12311 23812 10111 10511 59912 31612 67412 33412 Vimax54015 Viore11711 25811 47913 94915 Vision Quest68411 24912 Vivitek80213 44384 Vizio35011 40412 80016 20111 Wards74916 55514 81015 47811 71013 98215 54711 90015 56011 33411 Waycon70416 Wbox12618 23219 45211 Westinghouse58813 31912 44211 69314 11711 68515 48213 30611 43711 70713 01815 Westinghouse (Roku TV)44211 White-Westinghouse81017 53212 40411 90214 Windsor37811 Wyse34413 Xiaomi21012 Xoceco14011 14811 16611 Yamaha33411 79515 Zenith64512 53014 43311 40411 51712 95216 51011 15117 54411 57011 64311 63511 85913 66611 Zutest49611